

OBD2 GPS Tracking Unit - INSTALLATION INSTRUCTIONS

For CalAmp models LMU2000/3030



Step 1. Locate the OBD2 port, normally found in the driver's area below and to the left of the steering wheel at about knee height.

Plug the GPS Tracking unit into the port.

Note: In some vehicles, the OBD2 port is located such that the GPS unit may be knocked by the driver's knee, etc. For such circumstances, an extension cable is available that will allow you to locate the GPS unit more conveniently.

Step 2. Once installed, the two diagnostic lights should be solid. Note that the vehicle must be outside to acquire GPS signal. Note also that the **first time** a unit is being installed/activated, the green (GPS) light may take up to 10-15 minutes to change from flashing to solid, indicating it is now working.



Diagnostic Lights
Green - GPS
Orange - Network

Both Green and Orange
will be solid when unit is
working correctly.

When the lights are solid, the unit should be visible in your account in the GPS Tracking system. When first installed, it may take several minutes for the unit to show in the system.